

# WATER QUALITY SAMPLING CHECKLIST



DATE AND TIME ON LABEL



ADD TAPE OVER LABEL



PUT ON GLOVES



TRIPLE RINSE BOTTLES IN STREAM



COLLECT SAMPLES IN RIFFLE FACING UPSTREAM



FILL OUT DATASHEET



ADD 80 DROPS SULFURIC ACID (YELLOW BOTTLE) TO NUTRIENTS



ADD 40 DROPS NITRIC ACID (RED BOTTLE) TO TOTAL METALS



AFTER ADDING ACID CHECK BOX ON SAMPLE BOTTLE



CHECK LIDS ON TIGHT



ADD SAMPLES TO ICE CHEST WITH CUBED ICE



CONTACT ADEQ STAFF